



AUCKLAND INTERNATIONAL AIRPORT

AKL

S19

COORDINATION PARAMETERS

RUNWAY

Not currently coordinated

RUNWAY MAINTENANCE WINDOW

Runway closed between 01:30 to 04:30 LT every Monday morning

Last Departure slot before closure 0115

Last Arrival slot before closure 0130

First Departure slot after closure 0425

First Arrival slot after closure 0445

INTERNATIONAL TERMINAL

S19 (31 March 2019 to 26 October 2019)

[pax/h]

Arrivals Limit:	1250 Passengers per 30 Minutes, rolling every 5 minutes
	2150 Passengers per 60 Minutes, rolling every 5 minutes
Departures Limit:	2000 Passengers per 60 Minutes, rolling every 5 minutes