

## AUCKLAND INTERNATIONAL AIRPORT AKL COORDINATION PARAMETERS

## NS22 (27 March 2022 to 30 October 2022)

RUNWAY

Not currently coordinated

## **RUNWAY MAINTENANCE WINDOW**

Runway closed between 01:30 to 04:30 LT every Saturday and Monday morning Last Departure slot before closure 0115 Last Arrival slot before closure 0130 First Departure slot after closure 0425 First Arrival slot after closure 0445

## **INTERNATIONAL TERMINAL**

[pax/h]	
Arrivals Limit:	1250 Passengers per 30 Minutes, rolling every 5 minutes
	2150 Passengers per 60 Minutes, rolling every 5 minutes
<b>Departures Limit:</b>	2000 Passengers per 60 Minutes, rolling every 5 minutes