

## ARAR INTERNATIONAL AIRPORT (RAE) – S26 CAPACITY DECLARATION

### Runway

Open - 0300 UTC to 1900 UTC

#### R60 capacity limit

UTC Hour	03:00	to	19:00
Arrival limit	6		
Departure limit	6		
<b>Total</b>	12		

#### R10 capacity limit

UTC Hour	03:00	to	19:00
Arrival limit	1		
Departure limit	1		
<b>Total</b>	2		

### Terminal

#### Departure capacity limit

T60/15	Time UTC	PAX	Load Factor
International	0300-1900	400	95%
Domesti	0300-1900	400	95%

#### Arrival capacity limit

T60/15	Time UTC	PAX	Load Factor
International	0300-1900	400	95%
Domestic	0300-1900	400	95%

### Check-in

12 counters.

Domestic narrowbody flights open 180 minutes before STD, closes 60 minutes before STD.

International narrowbody flights open 180 minutes before STD, closes 60 minutes before STD.

6 counters per narrowbody Domestic flight.

6 counters per narrowbody international flight.

Commercial stands	Total stands		Code-C		Code-E MARS	
	Contact	Remote	Contact	Remote	Contact	Remote
Apron	4	3	2	1	2	2
<b>Total stands</b>	4	3	2	1	2	2

### Miscellaneous

- GABA slot requests are managed by airport directly.