

Bournemouth Airport

Winter 2025

Times UTC

RunwayTotals

R60

00:00	01:00	02:00	03:00	04:00	05:00	06:00	07:00	08:00	09:00	10:00	11:00	12:00	13:00	14:00	15:00	16:00	17:00	18:00	19:00	20:00	21:00	22:00	23:00
0	0	0	0	0	30	30	30	30	30	30	30	30	30	30	30	30	30	30	30	30	30	30	30

Runway Arrivals

R60

00:00	01:00	02:00	03:00	04:00	05:00	06:00	07:00	08:00	09:00	10:00	11:00	12:00	13:00	14:00	15:00	16:00	17:00	18:00	19:00	20:00	21:00	22:00	23:00
0	0	0	0	0	20	20	20	20	20	20	20	20	20	20	20	20	20	20	20	20	20	20	20

Runway Departures

R60

00:00	01:00	02:00	03:00	04:00	05:00	06:00	07:00	08:00	09:00	10:00	11:00	12:00	13:00	14:00	15:00	16:00	17:00	18:00	19:00	20:00	21:00	22:00	23:00
0	0	0	0	0	20	20	20	20	20	20	20	20	20	20	20	20	20	20	20	20	20	20	20

RUNWAY 30 MINUTES

Max of x2 departures in any rolling 30min period (rolls every 5mins).

All Departures

T60/15 (hourly/rolls every 15mins)

00:00	01:00	02:00	03:00	04:00	05:00	06:00	07:00	08:00	09:00	10:00	11:00	12:00	13:00	14:00	15:00	16:00	17:00	18:00	19:00	20:00	21:00	22:00	23:00
0	0	0	0	0	500	500	500	500	500	500	500	500	500	500	500	500	500	500	500	500	500	500	500

International Arrivals

T60/15

00:00	01:00	02:00	03:00	04:00	05:00	06:00	07:00	08:00	09:00	10:00	11:00	12:00	13:00	14:00	15:00	16:00	17:00	18:00	19:00	20:00	21:00	22:00	23:00
0	0	0	0	0	500	500	500	500	500	500	500	500	500	500	500	500	500	500	500	500	500	500	500

Domestic Arrivals

T60/30

00:00	01:00	02:00	03:00	04:00	05:00	06:00	07:00	08:00	09:00	10:00	11:00	12:00	13:00	14:00	15:00	16:00	17:00	18:00	19:00	20:00	21:00	22:00	23:00
0	0	0	0	0	200	200	200	200	200	200	200	200	200	200	200	200	200	200	200	200	200	0	0

Runway maintenance night closure - NONE

Notes

Opening times (FR/TOM)

0620-2155z

Opening times (Other carriers)

0800-1955z

Cargo

Max two aircraft for parking

LOAD FACTORS	W23		W24		W25	
Charter and TOM scheduled	100	%	100	%	100	%
EZY / FR / LS	95	%	95	%	95	%
Other scheduled	80	%	80	%	80	%