



WINTER 2026

(25 OCTOBER 2026 – 27 MARCH 2027)

COORDINATION PARAMETERS

TABLE OF CONTENTS

1. RUNWAY	3
2. TERMINAL	4
3. SEAT LOAD FACTORS (%)	4
3.1. ALL AIRLINES	4
3.2. LUXAIR	5

1. RUNWAY

Runway is available for the scheduling of flights Sunday 25th October 2026 – Saturday 27th March 2027 on weekdays 1234567 (daily) as follows:

- Arrivals between 05:10 - 21:55
- Departures between 05:00 - 21:50

HOUR UTC	Monday			Tuesday			Wednesday			Thursday			Friday			Saturday			Sunday		
	ARR	DEP	TTL	ARR	DEP	TTL	ARR	DEP	TTL	ARR	DEP	TTL	ARR	DEP	TTL	ARR	DEP	TTL	ARR	DEP	TTL
22:00 - 04:55																					
05:00 - 05:55	12	19	30	12	19	30	12	19	30	12	19	30	12	19	30	12	19	30	12	19	30
06:00 - 06:55	12	19	30	12	19	30	12	19	30	12	19	30	12	19	30	12	19	30	12	19	30
07:00 - 07:55	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30
08:00 - 08:55	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30
09:00 - 09:55	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30
10:00 - 10:55	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30
11:00 - 11:55	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30
12:00 - 12:55	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30
13:00 - 13:55	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30
14:00 - 14:55	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30
15:00 - 15:55	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30
16:00 - 16:55	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30
17:00 - 17:55	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30
18:00 - 18:55	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30
19:00 - 19:55	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30	16	16	30
20:00 - 20:55	19	12	30	19	12	30	19	12	30	19	12	30	19	12	30	19	12	30	19	12	30
21:00 - 21:55	19	12	30	19	12	30	19	12	30	19	12	30	19	12	30	19	12	30	19	12	30
22:00 - 04:55																					

2. TERMINAL

The latest acceptance time at Check-In Counters (LAT) in accordance with the following Terminal coordination parameters is **-45minutes before STD**

Number of passengers per 60 minutes, rolling every 5 minutes (T60/05)						
HOUR UTC	HOUR LOCAL	Total Arrivals	Total Departures	Schengen Arrivals	Non-Schengen Arrivals	Non-Schengen Departures
05:00 - 05:55	06:00 - 06:55	2500	1700	-	525	700
06:00 - 21:55	07:00 - 22:55	2500	1500	-	525	700
Number of passengers per 30 minutes, rolling every 5 minutes (T30/05)						
HOUR UTC	HOUR LOCAL	Total Arrivals	Total Departures	Schengen Arrivals	Non-Schengen Arrivals	Non-Schengen Departures
05:00 - 05:55	06:00 - 06:55	2000	1070	-	-	-
06:00 - 21:55	07:00 - 22:55	2000	1070	-	-	-

3. SEAT LOAD FACTORS (%)

3.1. ALL AIRLINES

Type	Load Factor (Arrival + Departure)
Charter Flights	90
New Scheduled Services (EU / MEA)	80
New Scheduled int.-Cont.	100
A3	85
BA	70
CZ	135
EC	85
EN	70
FR	90
IV	80
KL	85
LH	75
LO	75
LX	60
SK	65
TK	75
TP	80
V7	90

3.2. LUXAIR

Airline	Month	Load Factor (Arrival + Departure)
LG 3-Digit	October	79
LG 4-Digit	October	80
LG 3-Digit	November	75
LG 4-Digit	November	75
LG 3-Digit	December	70
LG 4-Digit	December	75
LG 3-Digit	January	65
LG 4-Digit	January	69
LG 3-Digit	February	74
LG 4-Digit	February	72
LG 3-Digit	March	69
LG 4-Digit	March	72